



## Adhesive Banner Installation Instructions

Wall graphics are printed vinyl, and some care and patience must be exercised during installation to ensure satisfactory performance. Our adhesive banners are perfect for indoor use and suitable for temporary outdoor use. Please do not apply if the surface has been painted in last 30 days or if it is heavily textured.

### The following surfaces are OK to apply adhesive banner material:

- Smooth, non-textured matte-painted drywall
- Smooth, non-textured gloss-painted drywall
- Other smooth, non-textured, non-porous surfaces such as glass or metal
- Smooth, non-textured wallpaper
- Flat, smooth, finished wood surfaces such as doors and paneling

### These surfaces are NOT recommended:

- Textured wallpaper
- Textured walls (speckled, orange peel, etc.)
- Brick or concrete block
- Unpainted drywall
- Outdoor walls
- Vehicles
- Any other surface that is rough, textured, uneven or porous

### Step-by-step application instructions:

1. Clean the surface thoroughly and allow plenty of drying time. Do not use chemical cleaners!
2. If the material is rolled up, please lay the sheets out and allow one day for them to flatten out.
3. Start at the top edge and work toward the bottom.
4. If repositioning is necessary, please remove gently and then reapply.
5. After it is in its proper position, squeegee out bubbles by working from the center of the graphic outward.
6. Wipe the graphic with a soft, dry cloth to remove any dust or residue.